



# WIRING HARNESS MANUAL To Suit Hilux Switching

# **TOOLS REQUIRED:**

- a) Small Screwdriver
- b) Electrical Tape

#### **OPTIONAL:**

- a) Wire cutters
- b) Crimpers
- c) 1x female spade terminal

WARNING: 4WD Supacentre recommends that a qualified auto electrician installs this product and will not be held liable for any complication(s) that may arise due to the improper installation of this product.


# STEP 1:

1. Disconnect the harness from your battery. Locate the relay and remove it from the harness.



STEP 2:

Cut off the large piece of heat shrink that surrounds the relay plug and then remove the cable tie.



#### STEP 3:

Remove the black negative cable from the relay plug. (Do this by sliding a small screwdriver down alongside the terminal and bending the tab out of the way)



# STEP 4:

Remove the black wire from the back of the switch, pull it through the corrugated tube and then plug it into the back of the relay plug in the empty position. (This terminal may not have a tab, so you'll need to ensure it goes over the relay's male terminal correctly)


Note: If you do not want excess wire around your engine bay, you can cut this black wire to the same length as the existing white wire and crimp on a new terminal before inserting into the relay plug






# STEP 5:

Replace the relay, making sure all four terminals are contacting correctly.



# STEP 6:

tape up excess wires, tape up exposed connection on black wire and tape relay plug and wiring loom to ensure it is secure.



STEP 7:

Test loom works correctly, then install.

Note: This wiring method will not allow the LED in the switch to illuminate.

The headlight adapter should be as per factory for this setup to work. Please see below:





# 12 MONTH LIMITED WARRANTY

#### **WARRANTY PERIOD:**

Full 12 month warranty from date of purchase against all manufacturing defects.

#### WHAT DOES THE WARRANTY COVER?

Under normal usage conditions, this warranty covers:

- a. Any defect in design or manufacture which results in the product failing to perform substantially as described in authorised advertising or literature.
- b. We will either repair or replace the product at our discretion providing that the fault is found to have been caused by a design or manufacturing defect and not misuse or tampering.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. The benefits provided to you as the consumer by this warranty are in addition to other rights and remedies available to you under the law.

#### THE WARRANTY DOES NOT COVER:

- a. Any damage resulting from improper use
- b. Faulty installation or modification made during installation
- c. The cost of removing and reinstalling the product
- d. Travel and /or other expenses due to customer's remote location
- e. Transport charges and damage in transit. It is your responsibility to deliver and pick up your product, including any costs associated with the postage of your repair or replacement product. If you do freight your product we recommend that you insure against loss or damage.
- f. Any loss directly or indirectly associated with the product failing to operate.
- g. Damage caused by mould, insects, animals, misuse, incorrect operation, adverse weather, accidents and fair wear and tear

TO MAKE A CLAIM, PLEASE ENSURE YOU RETAIN YOUR SALES RECEIPT OF PURCHASE

CALL 1800 88 39 64



OUTDOOR SUPACENTRE PTY LTD 2 Stanley St Silverwater NSW, 2128

PHONE: 1800 88 39 64 www.4wdsupacentre.com.au