



Inflatable Stand Up
Paddle Board
USER MANUAL



**PLEASE
READ AND
UNDERSTAND
THIS MANUAL
COMPLETELY
BEFORE
USING THE
PRODUCT**



WARNINGS & SAFETY INFORMATION

- Perform a thorough check of the board before use; do not use the board if it is damaged.
- Always wear a lifejacket (personal floatation device).
- Do not use the board in adverse conditions.
- Do not take sharp objects onto the board.
- Take care of sharp objects, such as coral and debris below the surface and on the bank.
- Do not tow the board with a watercraft.
- Do not over inflate or under inflate the board.
- If a puncture or leak occurs, return to the shore immediately.
- Do not use the board if you cannot swim.
- Never use the board alone.
- Do not use in white-water.
- Do not use in the presence of strong winds or currents.
- Do not use the board in waves higher than 0.3m.
- This board is not intended to be used by children under the age of 14. In addition to this, adults with reduced physical or mental capabilities, or those who are under the influence of drugs or alcohol should not use the board.
- No-more than one person should be on the board at a time.
- Do not exceed a distance greater than 150m from land.

THE MAXIMUM AIR PRESSURE FOR THIS PRODUCT IS 18PSI (124KPA), OVERINFLATING THE BOARD WILL VOID WARRANTY AND CAN RESULT IN DAMAGE TO BOTH THE USER AND THE BOARD.

SET-UP:

1. Remove the board roll from the bag and lay it on a flat surface with ample room.
2. Connect the fin.
3. Connect the air pump and inflate to **15PSI (103KPA)**.
4. Disconnect the air pump and lock the valve in the closed position.

PACK-UP:

1. Dry the board and place it on a flat surface.
2. Push in the valve and turn to lock in the open position.
3. Remove the fin.
4. Once the board is deflated, start rolling the board from the nose, pushing the remaining air out.
5. Pack the bag into the included carry bag.



12 MONTH LIMITED WARRANTY

WARRANTY PERIOD:

Full 12 month warranty from date of purchase against all manufacturing defects.

WHAT DOES THE WARRANTY COVER?

Under normal usage conditions, this warranty covers:

- a. Any defect in design or manufacture which results in the product failing to perform substantially as described in authorised advertising or literature.
- b. We will either repair or replace the product at our discretion providing that the fault is found to have been caused by a design or manufacturing defect and not misuse or tampering.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. The benefits provided to you as the consumer by this warranty are in addition to other rights and remedies available to you under the law.

THE WARRANTY DOES NOT COVER:

- a. Any damage resulting from improper use
 - b. Faulty installation or modification made during installation
 - c. The cost of removing and reinstalling the product
 - d. Travel and /or other expenses due to customer's remote location
 - e. Transport charges and damage in transit. It is your responsibility to deliver and pick up your product, including any costs associated with the postage of your repair or replacement product. If you do freight your product we recommend that you insure against loss or damage.
 - f. Any loss directly or indirectly associated with the product failing to operate.
 - g. Damage caused by mould, insects, animals, misuse, incorrect operation, adverse weather, accidents and fair wear and tear
-

TO MAKE A CLAIM, PLEASE ENSURE YOU RETAIN YOUR SALES RECEIPT OF PURCHASE

CALL 1800 88 39 64



OUTDOOR SUPACENTRE PTY LTD
2 Stanley St Silverwater NSW, 2128
PHONE: 1800 88 39 64
www.4wdsupacentre.com.au